



Parts List for DCD200B Type 1

| Item Number | Part Number | Description | Qty Required |
|-------------|-------------|----------------------|--------------|
| 1 | N510180 | TRANSMISSION | 1 |
| 2 | N467251 | HOUSING ASSEMBLY | 1 |
| 3 | N510196 | MOTOR & SWITCH ASSY. | 3 |
| 5 | N399342 | FWD/REV BUTTON | 1 |
| 6 | N392855 | DETENT SPRING | 1 |
| 7 | N393603 | SPEED SELECTOR | 1 |
| 8 | N377990 | SCREW | 4 |
| 9 | 682211-00 | SCREW PLASTITE | 10 |
| 10 | N466991 | SHROUD ASSY | 1 |
| 12 | 330065-31 | SCREW | 7 |
| 13 | N467070 | WASHER | 1 |
| 14 | 330065-25 | SCREW | 1 |
| 15 | N510198 | DRUM ASSY | 1 |
| 16 | N092854 | CHUCK SCREW | 1 |
| 17 | N467074 | DRUM | 1 |
| 20 | N470828 | PHILLIPS HEAD SCREW | 4 |
| 52 | N479576 | LED HOUSING | 1 |
| 53 | N476860 | LED ASSY | 1 |
| 54 | N039795 | SCREW | 1 |
| 55 | N467002 | SPRING | 1 |
| 56 | N467001 | PLUNGER | 1 |
| 57 | N510239 | FRONT HANDLE | 1 |
| 58 | N464902 | COVER | 1 |
| 59 | N464891 | CLAMP | 2 |
| 60 | N475709 | RETAINER RING | 1 |
| 61 | N464896 | NOSE | 1 |
| 62 | N476615 | FOAM SEAL | 1 |

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenetwork.com for current parts information.

Parts List for DCD200B Type 1

| Item Number | Part Number | Description | Qty Required |
|-------------|-------------|----------------------|--------------|
| 100 | N495891 | RATING LABEL | 1 |
| 101 | N495896 | LABEL WARNING ENG/FR | 1 |
| 102 | N503962 | WARNING LABEL (SPA) | 1 |
| 800 | N017298 | GREASE | 1 |
| 856 | DCD2005 | CABLE | 1 |
| 861 | N500566 | KITBOX | 1 |
| 866 | DCB203 | BATTERY PACK | 1 |
| 871 | DCB115 | CHARGER | 1 |

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.