

NOTES:

- 1. TO COMPLY WITH ANSI Z358.1-2009 FOR EMERGENCY EYEWASH OR EYE/FACE WASH AND SHOWER EQUIPMENT:
 - UNIT SHALL BE INSTALLED IN ACCORDANCE WITH MANUFACTURE'S INSTRUCTIONS AND ACCPTABLE PLUMBING PRACTICES
 - EYEWASH OR EYE/FACE WASH SHALL BE POSITIONED WITH NOZZLES NOT LESS THAN 83.8 CM (33 IN.) AND NO GREATER THAN 114.2 CM (45 IN) FROM SURFACE WHICH USER STANDS AND (15.3 CM (6 IN.) MINIMUM FROM WALL OR NEAREST OBSTRUCTION.
- 2. UNIT MUST BE LEVEL FROM FRONT TO BACK AND SIDE TO SIDE
- 3 ALL THREE MOUNTING HOLES ON MOUNTING BRACKET MUST BE USED TO PROPERLY SECURE EYEWASH UNIT TO WALL.
- 4. ****UNIT MUST BE FILLED WITH WATER BEFORE CONNECTING TO POWER** SOURCE.
- 5. PRIOR TO SERVICING/CLEANING: UNPLUG POWER CORD ON UNIT FROM POWER SOURCE AND REMOVE UNIT FROM MOUNTING BRACKET.
- 6. *DIMENSIONS MAY VARY ±1/2" (12.7mm)



©2016 Haws Corporation - All Rights Reserved. HAWS[®] and other trademarks used in these materials are the exclusive property of Haws Corporation.